


R	2, 3, 1, X, L	17, 1, 2, 18, 15,	3, 20, 23,	6, 9, 10,	11, 8,	12, 14,	41,
C	2, 3, 1, X, L	6, 38, 7, 34, 5, 8,	22, 33, 35,	24, 28,	25,	27, 29,	41,
L	3, 1, X, L	4, 6, 8, 5, 7, 9, 22, 23, 24, 25, 21,	10, 11, 12, 13, 13', 14,	15, 15', 16,	17, 1, 2, 18, 15,	19, 20, 21, 22, 23, 24, 25, 26, 27, 28, 29, 30, 31, 32, 33, 34, 35,	1, 2,



PATICE ELEKTRONEK



E1, E2, E3, E4, E5

ROZSAHY	SPOJENÉ DOTEKY P1
KV	1-2-3, 7-8-9, 13-14-15, 19-20,
SV	1-23-24, 5-6-7, 12-13, 17-18,
DV	22-23, 3-5, 15-19,

PŘEPÍNAČ P1

