


R	25, 34, 2, 24, 23,	1, 5,	10, 13, 27, 19, 15, 26,	10,	6,	9, 8, 7, 12, 18, 21, 14, 16, 11, 20, 22, 17,
C	3, 4, 5, 6, 40, 38,	7, 31,	33a, 12, 13, 14, 10, 39, 15, 16, 20, 17, 18,	42, 41, 19,	20,	36, 35, 21, 27, 22, 23, 28, 29,
L	1, 2, 4, 6, 3, 5, 7,	18, 19, 20, 20', 21,	22, 8, 10, 11, 9,	12, 13,	25,	30, 32,
					14, 15,	16, 17,




<https://teslaradio.webgarden.cz/>

ECH21 EM4 EBL21

ECH21

ECH21 AZ11

PATICE ELEKTRONEK



ROZSAHY	SPOJENÉ DOTEKY P1	SPOJENÉ DOTEKY P2
KV	3-5, 8-12, 15-17, 20-22-24	9-11,
SV	3-5,	15-17, 22-24,
DV		9-11,
Ω		4-6, 21-23,

